



# How to program the remote control of a BlackboxAV amplifier

## 1 2 different types of BlackboxAV amplifier

Please check the type of the amplifier in your MaxFire HD!

### 1.1 Amplifier without a RC program button



If your **amplifier has no blue button** at the front, please remove the amplifier from the Max Fire and send it to TAB Austria. We will modify the amplifier with a button to program the RC by your in future.

### 1.2 Amplifier with a RC program button



If your **amplifier has a blue button** at the front, you can program, the RC.

## 2 Program the remote control

1. Plug in power connector (230V 50Hz)
2. Press the program button for 4 seconds (LED starts flashing)
3. When LED has stopped flashing, press program button for 0,5 seconds
4. Press one of the RC buttons immediately (LED flashes once)
5. Programing the remote control finished

