

---

# KAHOATS

## User Manual



(Please read this User Manual carefully before you installing this product.)

---

# CONTENT

I .Features and description of games .....	1
II . DIMENSION AND TECHNICAL PARAMETER .....	4
III. Accessories list .....	5
IV . The structure of machine .....	6
V 、 Installation ,fixed and moving .....	7
VI. Methods of power connection .....	8
VII、 Power box description .....	8
VIII . Use and maintenance guide .....	9
IX. BACKSTAGE SETTING .....	10

---

## I .Features and description of games

### Features

1. Redemption machines.
2. The game is new, exciting and entertaining.
3. The appearance is elegant, colorful and delicate.
4. Used with large-scale integrated circuits and built-in programs. The functionality is stable and reliable.
5. Used with high quality ticket dispenser.
6. Meet the general type of tickets.
7. Use high quality coin selector, the diameter of coins can be adjusted from 20mm to 28mm,which is accurate and stable.
8. Game programming and revenue ratio are easily to adjust.

## How To Play

1. Inset coins, press the button to start the game.



2. Throw balls into the square holes and get scores.



There is different score of different monster.



3. After game, the higher score you get, the more tickets you will win.



If your score is higher than the jackpot score, you can win jackpot tickets.



## II . DIMENSION AND TECHNICAL PARAMETER

1. Voltage: AC220V±5% 50Hz or AC 110V±5% (or make the reference with the mark);
2. Power: 800 W;
3. Dimension: W1228\*D2245\*H2890mm








4. Weight: About 300kg;
5. THE TEMPERATURE : (INDOOR)TEMPERATURE: -10~+40℃ TEMPERATURE:  
≤90%;PRESSURE: 86Pa~106Pa.


### III. Accessories list

In order to use the machine normally , Please check it carefully after you open the package box to see whether it have the following items:

- (1) A main machine;
- (2) A set of repair parts, list as the below

No.	Parts name	Specification	QTY		Picture	Remark
1	Power line	1. 8m	1	PC		
2	Fuse Tube	5XΦ20mm	2	PC		10A
3	User Manual		1	PC		
4	Key of Coin box	AH78	2	PC		
5	Key of maintenance door	AH57	3	PC		Front door and back door

#### IV. The structure of machine






---

## V 、 Installation ,fixed and moving

1. This machine only can be use in the indoor, outdoor is prohibited;  
It will affect the function if you use it outdoor.

2. Range for placement:


The machine should be placed as the following range, enough space can make it cool down better.



4、 When moving it , you must pay attention to the following:

- (1) You must turn off the power and pull the power connection out before moving.
- (2) If the caster can not move, please change the castors.
- (3) Any moving, turning and transport artificial random could damage the device and destroyed the mechanical properties .
- (4) Confirmed the process of moving , flipping and transportation meet the manufacturers requirements.

## VI. Methods of power connection




Look-out:

Power cord can not be pressed by heavy objects, which would easily cause short circuit and may lead to serious fires.

1. When you pull the power cord out from the socket, you should seize the plug prefer grasp the wire.
2. Can not pull the plug directly with wet hands.
3. Can not force stretched and twisted the power cord, and the power cord can not be expose or near the object which is in high temperatures.
4. The power cord can not be kicked or contact easily.
5. Must use the correct voltage and fuse (See the specification)

## VII、 Power box description



This machine uses AC“220V±5% 50HZ (or 110V±5% 60HZ)

- (1) The fuse is in fuse holder , the standard of fuse is “220V 6A diameter 5-20mm(or 110V 12V diameter 5-20mm)
- (2) The power switch is use for turn on/off the connection.
- (3) Ground terminal: connection with the dedicated ground.

---

## VIII. Use and maintenance guide

1. Machines for maintenance and repairs, you must turn off the power .

In order to avoid short circuit, the persons concerned access to machine internal components before you turn off the power source. If it requires power, shall meet the requirements of operating instructions

2. When you replace a component determines when the appropriate choice of accessories.

Use of incorrect parts can result in fire or electrical short circuit, damage to the Board, and no device

3. Don't arbitrarily split the Royal, Assembly, alter equipment. This can cause fire or an electrical short circuit, mechanical failures, and so on.

4. Confirm the move, flip, transport and so on to meet manufacturers request. Random people-moving, can damage equipment such as flip, transport, destruction of machinery performance.

5. This machine is suitable for indoor use, should not be used outdoors.

Outdoor use will affect the performance of the machine.

6. Not in the following places

- ★Place where leakage or high humidity
- ★Close to the places of high temperature objects
- ★Close to dangerous goods.
- ★Slippery or unstable place.
- ★Equipment close to the spark
- ★Shock serious place
- ★Dusty environment


7. Do not place a vase filled with water in the above, cups. container, or placing chemicals above and very heavy.

Liquid overflow will cause electrical short circuit damage devices, chemical corrosion machine, will harm the human body falling from a height and destruction of the machine.

8. Do not place objects at the vent being blocked will cause the temperature rise, affect the functioning of machines or even damage the device.

---

## IX. BACKSTAGE SETTING



1. Game Setting: Enter game setting menu
2. Sound Setting: Enter sound setting menu
3. Player Input output: Input and output for general function
4. Record: To enter the record menu
5. Restore Default Setting: Restore Default Setting
6. Exit: Back to game


## Game Setting

	中文	english
● language		
once game coins	2	
game time	15	
LOGO	show	
out ticket	on	
ticket score rate	10	
min tickets	5	
monster min score	5	
monster max score	200	
bonus tickets	5	
bonus score over	2500	
bonus score limit	500	
bonus decrease score	100	
game title	kahouts	
return		

1. Language: To set the language
2. Once game coins: To set the coins qty per game
3. Game Time: To set time of game
4. LOGO: To set if the LOGO shown in the screen
5. Out Ticket: To set ticket out or not
6. Ticket score rate: To set the how many scores for a ticket
7. Min Ticket: To set the minimum qty of tickets
8. Monster Min Score: To set the minimum score of monsters
9. Monster Max Score: To set the maximum score of monsters
10. Bonus Tickets: To set the qty of jackpot tickets
11. Bonus Score Over: To set upper limit of jackpot tickets
12. Bonus Score Limit: To set lower limit of jackpot tickets
13. Bonus Decrease Score: To set the decrease score for jackpot when failing to get jackpot in a game.
14. Game Title: To set the game title of game
15. Return: Back to last menu




## Sound Setting



1. Sound Volume: To set the volume of game effect music
2. Bgm Volume: To set the volume of background music
3. Idle Mute: Mute mode or not
4. Return: Back to last menu


## Player Input Output



1. Start Key: To test start button
2. Open Sensor: To test sensor of ball block up
3. Close sensor: To test sensor of ball block down
4. Sensor 1-8: To test the sensor of hole 1-8
5. Player: To choose output test for 1P, 2P
6. Idle: To test the LED function in attraction mode
7. Door: To test motor of ball block
8. Start light: To test led of start button
9. Light 1-8: To test led of holes 1-8
10. Return: Back to last menu


---

## Other Input Output



To test LED strips

## Game Record



To record total coins and tickets